MESSAGE BOX

- A message box is a predefined dialog box that displays a message for the user. A message can be displayed to alert the
 user to invalid data or as a reminder of options required for an application to continue.
- The MessageBox object includes a Show() function for displaying a message box and is used in a statement that takes
 the form:

```
MessageBox.Show("Message");
```

To display a message box with specified text, a caption in the title bar and an OK button.

```
MessageBox.Show("Message", "Caption");
```


. To display a message box with specified text, a caption, and one or more specific buttons.

```
MessageBox.Show("Message", "Caption", MessageBoxButtons.OKCancel);
```

To display a message box with specified text, a caption, buttons, and an icon.


```
... "Caption", MessageBoxButtons.OKCancel, MessageBoxIcon.Exclamation);
```

In all these statements, Message is the text to display in the message box, Caption determines what appears in the title
bar of the message box, Buttons determines which buttons the user sees, and Icon determines what icon (if any) appears
in the message box.



MESSAGE BOX BUTTONS

MESSAGE BOX ICONS



SETTING THE DEFAULT BUTTON

Along with displaying the appropriate buttons, you can instruct the message box to set a default button for you. This
allows the user to read the message and press the Enter key to invoke the action for the default button without having to
click the button itself with the mouse.

```
... MessageBoxIcon.Exclamation, MessageBoxDefaultButton.Button2);
```

Member Name Description

- Button1 Specifies that the first button should be the default button.
 - Button2 Specifies that the second button should be the default button.
 - Button3 Specifies that the third button should be the default button.